

The Louvre Lounge



Timber Deck Installation

TIMBER FOUNDATION INSTALLATION

Using M10 timber screws, a minimum of 80mm embedment (d) is required for low wind-rated areas. For high wind-rated areas, a minimum embedment (d) of 120mm is required however, please consult a professional. Fasten 4 screws per post. Each screw must be embedded into a joist or noggin to ensure strength and safety.

